

Bypassing

Turn valve to "RECIRCULATE". This will bypass the filter media.

NOTE: The beneficial bacteria in your filter are aerobic which means it needs oxygen to keep living. You can keep the bacteria oxygenated during the medicating of your pond without allowing the medication to contact your bacteria by following this simple procedure:

- 1) Turn off the pump
 - 2) Turn valve to "RINSE"
 - 3) Open ball valve and turn on blower for 30 seconds
 - 4) Turn off blower and close ball valve
 - 5) Turn valve back to "RECIRCULATE"
 - 6) Turn pump back on
- This procedure should be performed once every three hours for as long as the beads are being bypassed*

This procedure oxygenates the beneficial bacteria in the filter